

Instruction Sheet

PA-00364
June 2013

AOFD POE OIL FILTER DRIER

AOFD POE Oil Filter Drier

SAFETY INSTRUCTIONS

1. Read all instructions thoroughly. Failure to do so may result in system damage and/or personal injury.
2. Emerson's AOFD is intended for use with all HFC, HCFC and CFC refrigerants except those classified by ASHRAE standard 34 as A2, A3, B2 & B3.

CAUTION: Do not use on unlisted gases or fluids without prior approval of the Emerson Climate Technologies Flow Controls Division Applications Engineering Department. Use on other fluids could result in product deterioration.

WARNING: Do not attempt to install AOFD before pumping the system down to atmospheric pressure. The use of approved refrigerant recovery equipment may be required. Make absolutely certain that the pressure in the lines is at atmospheric pressure before removing the AOFD.

INSTALLATION INSTRUCTIONS

1. Place between oil separator and crankcase or oil reservoir, carefully following flow direction.
2. Install sight glass in the line after outlet of POE oil filter drier.
3. Replace when the sight glass shows a decrease in oil flow or when more than 15 psig drop is noted between inlet and outlet of the POE Oil Filter Drier.